

Frequencies Authorized to Use on your Boat

Lower end KHz	High end KHz	Allocation	Sideband
1,800	2,000	Amateur 160 Meters	(LSB)
2,003	Select	Maritime Mobile	(USB)
3,600	4,000	Amateur 80 Meters	(LSB)
4,000	4,033	Maritime Mobile	(USB)
6,224	6,230	Maritime Mobile	(USB)
7,125	7,300	Amateur 40 Meters	(LSB)
8,101	8,188	Maritime Mobile	(USB)
12,230	13,200	Maritime Mobile	(USB)
14,150	14,350	Amateur 20 Meters	(USB)
16,526	165,646	Maritime Mobile	(USB)
18,110	18,168	Amateur 17 Meters	(USB)
18,825	18,843	Maritime Mobile	(USB)
21,200	21,450	Amateur 15 Meters	(USB)
22,159	22,177	Maritime Mobile	(USB)
24,930	24,990	Amateur 12 Meters	(USB)
26,100	26,118	Maritime Mobile	(USB)
26,960	27,410	Citizens Band	(AM & SSB)
28,300	29,700	Amateur 10 Meters	(USB)

Requires Ship Station License

Requires General Class Amateur License

www.made-simple-for-cruisers.com

Cutout for your radio area.

Primary HF Ship to Ship Frequencies

ID	2 MHz	4 MHz	6 MHz	8 MHz	12 MHz
A	2065.0 kHz	4146 kHz	6224 kHz	8294 kHz	12353 kHz
B	2079.0 kHz	4149 kHz	6227 kHz	8297 kHz	12356 kHz
C	2093.0 kHz		6230 kHz		12359 kHz
D	2096.5 kHz				12362 kHz
E	2214.0 kHz				12365 kHz
F					
G					
ID	16 MHz	18 MHz	22 MHz	25 MHz	
A	16528 kHz	18825 kHz	22159 kHz	25100 kHz	
B	16531 kHz	18828 kHz	22162 kHz	25103 kHz	
C	16534 kHz	18831 kHz	22165 kHz	25106 kHz	
D	16537 kHz	18834 kHz	22168 kHz	25109 kHz	
E	16540 kHz	18837 kHz	22171 kHz	25112 kHz	
F	16543 kHz	18840 kHz	22174 kHz	25115 kHz	
G	16546 kHz	18843 kHz	22177 kHz	25118 kHz	